

When adding Receivers to motors, check that the motor's power supply does not have sleep mode like Merlin has.

Stand Alone Receivers Me Install

The ATA

- Positive wire is on the right of the block (+)
- Make sure you have constant power and no voltage drop.
- It's the same as the paper works says
- Press and hold the receiver button you want to use and HOLD IT
- Then press the Remote button you want to use once (Then the light flashes quicker)
- The wait 2 seconds
- Then press the same button on the remote and let it go along with the receivers button (Let it go to)
- Wait 10 seconds
- And then test it as it will work.
- Deleting all codes from unit
- Switch the power off
- Then push and hold SW1 button down and don't let go
- Switch the power on
- Then hold the button down still for 15 seconds till the light changes
- Then let the button go and all codes will be erased

FAAC White Receiver (The black one is push the 2 button thing)

- **Positive wire is on the left of the block (+)**
- Clear all codes
- Press and hold the SW1 button and don't let go
- The the light flashes slow
- The it flashes fast
- Then both lights come on steady and then go out
- Let go and its erased
- **Programming a white remote**
- Press the SW1 or the SW2 button once
- Then the light will come on
- Don't hold the remote to close to the receiver as it don't like it
- Then on the remote press the button you want to use straight away quick (Don't stuff around) and then hold it till the light goes steady for a bit
- Then let it go
- Then push the same button a second time quickly and let go and the light should go steady red again.
- Then it will go off after 5 seconds
- **Wait 10 seconds for it to program its self**
- **And it should work.**