

Dominator Instructions

Switch off power to the motor from the power point

Switch power back on

Immediately press the program button (located on the back of the motor) two times quickly

The four led lights on the back of the motor will flash twice and the bottom light will come on and either be solid or flashing

If flashing this means a new remote can be programmed and you must press and hold a button on the NEW remote until the light goes out (choose any button you wish to operate your door)

If the bottom light is solid and was not flashing, this means a remote has already been stored in this channel and you must quickly press the program button on the back of the motor and the next led will either flash or be solid (repeat the above step until you find a flashing light)

If all lights are solid you must push and hold the program button to clear this channel and release the program button once flashing

Next you will press and hold a button on the new remote

Wait 15 seconds and test the remote

www.remotepro.com.au

Use Smooth remote
And clone it
No programming it