

Stratco Made Unit 303Mhz only Stratco Remotes

WJYK REMOTE INSTALLATION INSTRUCTIONS

IMPORTANT!

PLEASE READ ALL INSTRUCTIONS BEFORE BEGINNING ANY CONNECTIONS

MAKE SURE 220VAC POWER SOURCE IS DISCONNECTED, BREAKER IS OFF AND NO ONE IS GOING TO BE WORKING ON THE POWER SUPPLY!

Electrical Connections:

The black wires should be connected to DC12V-

The red wires should be connected to DC12V+

The green wire is common

The yellow wire is No. 1 button

The blue wire is No.2 button

The white wire is No. 3 button

Learn transmitter:

Push the learn switch in the receiver for 1 second, release than push the transmitter button

Erase transmitter:

Push the learn switch for 15 second, all transmitters will be erased.

Once you have programmed button No1 then all the other buttons are programmed in automatically and assigned to the following wire relay.

Button No 1 triggers the Yellow wire relay.

Button No2 triggers the Blue wire relay.

Button No3 triggers the White wire relay.

To check if a remote is going to work on these Receivers as some are PTX4 Factory made | You simply press any button on the remote and see if there little Red Led is flashing slightly.

They do make these in a PTX4 Version so check