

When adding Receivers to motors, check that the motor's power supply does not have sleep mode like Merlin has.

Multi Receiver Ours



Universal Receiver Remote Control Compatible For Marantec Nice Flors Hormann

Specification:

Model Number: 967210

Product Name: Receiver

Condition: New

Material: Plastic

Size: 5.3cm*4cm*2cm(L*W*H)

Main Color: White

Type: Garage Door Receiver

Multi Frequency: 300-868Mhz

Compatible Model: Rolling Code & Fixed Code

Quantity: 1pc

Brand Selector: With 8 Dip Switches User Can Make Different Combination For Different Remote Brands.

Compatible:

For Nice Flors (433.92MHz)

For Marantec (433.92MHz)

For Universal Fixe Code/Codigo Fijo (433.92MHz)

For FaacsIh Rolling Code (433.92MHz)

For Liftmaster (433.92MHz)

For Universal Rolling Code (433.92MHz)

For Codigo Fijo (300.00MHz)

For Codigo Fijo (300.00MHz / 315.00MHz / 318.00MHz / 330.00MHz / 390.00MHz)

For Rollingcode Fixe Code(315.00MHz)

For Gojcm (868MHz)

For Liftmaster Rollingcode Billioncode (390.00MHz)

For Liftmaster Rollingcode (315.00MHz / 868.00MHz)

For Clemsa Matercode (433MHz)

For Hormann Marantec Berner (868.00MHz)

For FaacsIh (868.00MHz)

For Prastel (433.00MHz)

For Sommer (868.00MHz / 43334MHz)

For Chamberlain/Liftmaster/Motorlift:94330E,94333E,94334E,94335E-old,
94335E,84333EML,84330EML,84334EML,94335EML,84330E,84333E,84335E

For

Liftmaster/Chamberlain/Motorlift:4330E,4332E,4333E,4335E,4330EML,4332EML,4333EML,
4335EML

For Homentry PS94331,HE4331

(The Compatibility Is Just For Reference. Please Before Purchasing!)

And Many Other Main Brands In The Market...

Features:

-100% Brand New !

-High quality, suitable for a variety of remote control matching.

-Learn button and led: there are 2 independent channels. each channel has independent learn button s1, s2 and l1, l2.

-Power input selector: this receiver can work at ac/dc 12v~30v. however, it's better to change the pis according to the power input.

-If the input is great than 24V, shorten pin 2&3; shorten 1&2 if input less than 24V.

-Mini Size, can work with 400 codes.

-It don't interference other remotes and receivers, and 2 independent relays

Program the remote steps:

1) First, select the correct brand for remote that will be entry (by dip switch)

2) Press the learning button 1 or 2, the corresponding LED turns on

3) Press the button on the remote, the led 1 or led 2 flashes 4 times, the remote button is learned successfully

How to delete code:

Press and hold either learn button. The LED will start flash. Keep this button pressed, until the LED will turn off. All saved data in the memory card will be erased permanently and cannot be recovered

Select switches as to the following to work with.

-