



→ GRATCO MADE UNIT
303MHz "only Gratco"

WJYK REMOTE INSTALLATION INSTRUCTIONS

IMPORTANT!

PLEASE READ ALL INSTRUCTIONS BEFORE
BEGINNING ANY CONNECTIONS

MAKE SURE 220VAC POWER SOURCE IS
DISCONNECTED, BREAKER IS OFF AND NO ONE IS
GOING TO BE WORKING ON THE POWER SUPPLY!

Electrical Connections:

- The black wires should be connected to DC12V-
- The red wires should be connected to DC12V+
- The green wire is common
- The yellow wire is No. 1 button
- The blue wire is No. 2 button
- The white wire is No. 3 button

Learn transmitter:

Push the learn switch in the receiver for 1 second, release then push the transmitter button

Erase transmitter:

Push the learn switch for 15 second, all transmitters will be erased.

Once you have programmed button 1 in then all the other
buttons will be programmed automatically.

Button No1 will trigger Yellow wire switch

Button No2 will trigger Blue wire switch.

Button No3 will trigger White wire switch

Notes: This unit is also made with a Pix 4 Circuit Board.

To check what Remotes Work/Paers one on the
Receiver and the Red Led will Kllickes slightly