



Connect pre-wired cables to  
XW81 & XN70

### Programming Secura-Lock

|  |   |  |   |
|--|---|--|---|
|  | The opener must be switched on  |  | <i>Solid ON icon displayed</i>              |
|  | Hold the P button for at least 10 seconds   |  | <i>Counter flashes &amp; menu displayed</i> |
|  | Select <b>Level 1</b> using the + and - buttons<br><i>This Level is for Basic functions</i>                   |  | <i>Level value displayed</i>                |
|  | Press and release the P button to confirm the level   |  | <i>Menu &amp; Parameter value displayed</i> |
|  | Select <b>Menu 7</b> using the + and - buttons<br><i>This is the Relay Output Menu</i>                        |  | <i>Parameter value displayed</i>            |
|  | Press and release the P button to confirm the menu  |  | <i>Parameter value will flash</i>           |
|  | Select <b>Parameter 9</b> using the + and - buttons<br><i>This is the Locking Mechanism Release Parameter</i> |  | <i>Parameter value will flash</i>           |
|  | Press and release the P button to confirm the parameter   |  | <i>Level 1 will be displayed</i>            |
|  | Hold the P button for at least 5 seconds to exit menu<br><i>Programming complete</i>                          |  | <i>Solid ON icon displayed</i>              |