

This procedure is used to schedule a maintenance/servicing interval. The opener will display a servicing reminder once the required number of door operations are completed.



Set Servicing Interval

	The opener must be switched on		Solid ON icon displayed																																				
	Hold the P button for at least 10 seconds		Counter flashes & menu displayed																																				
	Select Level 7 using the + and - buttons <i>This Level is for Maintenance & Servicing functions</i>		Level value displayed																																				
	Press and release the P button to confirm the level		Menu value displayed																																				
	Select Menu 3 using the + and - buttons <i>This is the Servicing Interval Menu</i>		Parameter value displayed																																				
	Press and release the P button to confirm the menu		Parameter value will flash																																				
 	Select Parameter as per the table below: <table border="1" data-bbox="236 1258 1104 1644"> <thead> <tr> <th>Parameter</th> <th>Door Operations</th> <th>Parameter</th> <th>Door Operations</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>OFF</td> <td>9</td> <td>8,000</td> </tr> <tr> <td>2</td> <td>100</td> <td>10</td> <td>9,000</td> </tr> <tr> <td>3</td> <td>500</td> <td>11</td> <td>10,000</td> </tr> <tr> <td>4</td> <td>1,000</td> <td>12</td> <td>15,000</td> </tr> <tr> <td>5</td> <td>4,000</td> <td>13</td> <td>20,000</td> </tr> <tr> <td>6</td> <td>5,000</td> <td>14</td> <td>30,000</td> </tr> <tr> <td>7</td> <td>6,000</td> <td>15</td> <td>40,000</td> </tr> <tr> <td>8</td> <td>7,000</td> <td>16</td> <td>50,000</td> </tr> </tbody> </table> <i>(Example used - 4,000 door operations)</i>	Parameter	Door Operations	Parameter	Door Operations	1	OFF	9	8,000	2	100	10	9,000	3	500	11	10,000	4	1,000	12	15,000	5	4,000	13	20,000	6	5,000	14	30,000	7	6,000	15	40,000	8	7,000	16	50,000		Parameter value will flash
Parameter	Door Operations	Parameter	Door Operations																																				
1	OFF	9	8,000																																				
2	100	10	9,000																																				
3	500	11	10,000																																				
4	1,000	12	15,000																																				
5	4,000	13	20,000																																				
6	5,000	14	30,000																																				
7	6,000	15	40,000																																				
8	7,000	16	50,000																																				
	Press and release the P button to confirm the parameter		Menu 7 will be displayed																																				
	Hold the P button for at least 5 seconds to exit menu <i>Programming complete</i>		Solid ON icon displayed																																				

A service reminder will be displayed after selected number of door operations have been completed.

Servicing Counter

	The opener must be switched on		Solid ON icon displayed
	Hold the P button for at least 10 seconds		Counter flashes & menu displayed
	Select Level 7 using the + and - buttons <i>This Level is for Maintenance & Servicing functions</i>		Level value displayed
	Press and release the P button to confirm the level		Menu value displayed
	Select Menu 2 using the + and - buttons <i>This is the Servicing Counter Menu</i>		Menu value displayed
	Press and release the P button to confirm the menu <i>Number of door operations remaining until servicing reminder will be displayed (one figure at a time)</i>		Counter will flash
	Hold the P button for at least 5 seconds to exit menu		Solid ON icon displayed

Reset Servicing Interval

	The opener must be switched on		Solid ON icon displayed
	Hold the P button for at least 10 seconds		Counter flashes & menu displayed
	Select Level 7 using the + and - buttons <i>This Level is for Maintenance & Servicing functions</i>		Level value displayed
	Press and release the P button to confirm the level		Menu value displayed
	Select Menu 3 using the + and - buttons <i>This is the Servicing Interval Menu</i>		Parameter value displayed
	Press and release the P button to confirm the menu		Parameter value will flash
	Select Parameter 1 using the + and - buttons		Parameter value will flash
	Hold the P button for at least 5 seconds to confirm and exit menu <i>New servicing interval can now be programmed</i>		Solid ON icon displayed