

## Configuration

You can click the right top corner edit button (see below FIG 16) to get more functions.

You can change the Device Name and Device Location. You can test if the device is connected by clicking "Check Device Network".

You can also "Share Device", "Create Groups" "Check for Firmware Upgrades" and "Remove Device". (see below FIG 17). For information on how to use these features or use the app click on "Help and Feedback".




FIG.16




FIG.17

## Changing Account or Device

If you need to use a new mobile phone to control the opener, log in with your original app account by your new mobile phone.

If you also need to change to a new account, you have two options.

### Option 1: Remove Device from App

Click "Remove Device" to delete the opener information in your original account (see FIG 17), keep the garage door opener powered on and WiFi connected and then re-connect the opener in the new account step by step.

### Option 2: Reset Garage Door Opener

If there is no network, restore the factory settings on garage door opener.

- 1) Press "set" button in the opener and hold until "7" displays on the screen
- 2) Press "up" button in the opener, "1" will be displayed on the screen
- 3) Press "set" button one time, the below pattern will be displayed and that means the WiFi connection of opener has been restored.



## GDO WiFi Connection Manual

### Read First

Before the WiFi function can be activated, the garage door opener opening and closing position must have been set.

1. Ensure your router, smart phone and device are as close as possible. Make sure that your WiFi has a 2.4G network enabled.
2. Only one user account can be used to control the garage door opener. Make sure the garage door opener has not been previously connected to another account.

### Setup

1. Download the "Smart GDO" App to your smart phone via Google play (for android) or App store (for IOS).

Or use your smart phone to scan the QR code. Press the right top corner, to open with browser to download the app.




FIG.1



FIG.2

FIG.3

FIG.4

2. Open the App and create a new account according to the instructions. If you already have an account, log in directly.

- 1) Click the "Register" button
- 2) Fill in your mobile number
- 3) Click the "Get verification code" button
- 4) Fill in your received code from your mobile phone
- 5) Set password



FIG.5



FIG.6




FIG.7




FIG.8

3. Click "Add Device" and choose "Garage", then click "Confirm indicator rapidly blink" button.



FIG.9



FIG.10



FIG.11

4. Choose the appropriate WiFi network, enter the password, and then click the "Confirm" button (see FIG 12). The opener will then connect to your network (see FIG 13). This may take up to 2 minutes.



FIG.12




FIG.13



FIG.14

5. Garage door opener WiFi setting

- 1) While the smart phone app is attempting to connect, press "set" button on the garage door opener and hold until "6" displays on the screen.
- 2) Then "0" displays on the screen and will keep blinking, while the garage door opener is connecting with the WiFi.



6. Go back to App and click "Done" (see FIG 14). Only one account can be linked to the opener.

If connection fails (see FIG 15), repeat the above steps to retry.




FIG.15